

STANDARD ARRIVAL ROUTES

- GENERAL:

Surveillance service shall be available.
- LOSS OF RNAV CAPABILITY:

Request vectoring.
- VECTORIZING:

Vectoring may be used for sequencing.
- RADIO COMMUNICATION FAILURE:

Squawk A7600. Proceed on STAR and make APCH to RWY 35.

DESIGNATOR	ROUTE	RESTRICTIONS	DESCEND	CLEARANCE LIMIT
ALUVA 2P (ALUVA TWO PAPA ARRIVAL)	From ALUVA to GENVU, to OKLAN, to BR725, to IBLIR, to BR722, to BR721, to BR720, turn left to RIVIP.	Cross ALUVA at or above FL 90. Cross IBLIR BTN 8000 FT and 4000 FT. MAX 220 KT IAS at IBLIR. Cross RIVIP at or above 4000 FT.	As cleared by ATC.	RIVIP
BADAB 2P (BADAB TWO PAPA ARRIVAL)	From BADAB to OKTOS, to DIBMA, to LEGTA, to LATSI, to BR735, turn left to RATUG, to BR732, to BR731, to BR730, turn right to GODID.	Cross OKTOS at or above FL 90. Cross RATUG BTN 8000 FT and 6500 FT. MAX 220 KT IAS at RATUG. Cross GODID at or above 4000 FT.	As cleared by ATC.	GODID
ETNOR 1P (ETNOR ONE PAPA ARRIVAL)	From ETNOR to LELMI, to BR724, to BR723, to IBLIR, to BR722, to BR721, to BR720, turn left to RIVIP.	Cross ETNOR at or above FL 90. Cross BR724 BTN 8000 FT and 4000 FT. MAX 220 KT IAS at BR724. Cross IBLIR BTN 8000 FT and 4000 FT. MAX 220 KT IAS at IBLIR. Cross RIVIP at or above 4000 FT.	As cleared by ATC.	RIVIP
GENVU 1P (GENVU ONE PAPA ARRIVAL)	From GENVU, to OKLAN, to BR725, to IBLIR, to BR722, to BR721, to BR720, turn left to RIVIP.	Cross IBLIR BTN 8000 FT and 4000 FT. MAX 220 KT IAS at IBLIR. Cross RIVIP at or above 4000 FT.	As cleared by ATC.	RIVIP
LUNUR 3P (LUNUR THREE PAPA ARRIVAL)	From LUNUR to BR737, to ROXET, to BR734, to BR733, to RATUG, to BR732, to BR731, to BR730, turn right to GODID.	Cross LUNUR at or above FL 100. Cross BR737 at or above 8000 FT. Cross BR734 BTN 8000 FT and 6500 FT. MAX 220 KT IAS at BR734. Cross RATUG BTN 8000 FT and 6500 FT. MAX 220 KT IAS at RATUG. Cross GODID at or above 4000 FT.	As cleared by ATC.	GODID
MODNI 2P (MODNI TWO PAPA ARRIVAL)	From MODNI to BR727, to BR726, to BR724, to BR723, to IBLIR, to BR722, to BR721, to BR720, turn left to RIVIP.	Cross BR727 at or above FL 90. Cross BR724 BTN 8000 FT and 4000 FT. MAX 220 KT IAS at BR724. Cross IBLIR BTN 8000 FT and 4000 FT. MAX 220 KT IAS at IBLIR. Cross RIVIP at or above 4000 FT.	As cleared by ATC.	RIVIP
NIDGI 2P (NIDGI TWO PAPA ARRIVAL)	From NIDGI to NIDIN, to LELMI, to BR724, to BR723, to IBLIR, to BR722, to BR721, to BR720, turn left to RIVIP.	Cross NIDGI at or above FL 90. Cross NIDIN at or above 6000 FT. Cross BR724 BTN 8000 FT and 4000 FT. MAX 220 KT IAS at BR724. Cross IBLIR BTN 8000 FT and 4000 FT. MAX 220 KT IAS at IBLIR. Cross RIVIP at or above 4000 FT.	As cleared by ATC.	RIVIP
PESUR 3P (PESUR THREE PAPA ARRIVAL)	From PESUR to BR736, to BR734, to BR733, to RATUG, to BR732, to BR731, to BR730, turn right to GODID.	Cross PESUR at or above FL 100. Cross BR736 at or above 8000 FT. Cross BR734 BTN 8000 FT and 6500 FT. MAX 220 KT IAS at BR734. Cross RATUG BTN 8000 FT and 6500 FT. MAX 220 KT IAS at RATUG. Cross GODID at or above 4000 FT.	As cleared by ATC.	GODID