

ENZV STAR RWY 10 (RNAV) – ROUTES

GENERAL:Surveillance service shall be available.

LOSS OF RNAV CAPABILITY:Request vectoring.

VECTORIZING:Vectoring may be used for sequencing.

DESIGNATOR	ROUTE	RESTRICTIONS	DESCEND	CLEARANCE LIMIT
BEGOD 2Q  (BEGOD TWO QUEBEC ARRIVAL)	From BEGOD, to ZV500, to ZV925, to BEVGU, to ZV923, to ZV922, to ZV921, to ZV920, turn left to OTBIG.	Cross ZV500 at or above 4000 FT. Cross ZV925 between 4000 FT and FL 80. MAX 220 KT IAS at BEVGU. Cross OTBIG at or above 3000 FT.	As cleared by ATC.	OTBIG
IDIPI 2Q  (IDIPI TWO QUEBEC ARRIVAL)	From IDIPI to ZV926, to ZV924, to BEVGU, to ZV923, to ZV922, to ZV921, to ZV920, turn left to OTBIG.	Cross IDIPI at or above FL 100. Cross ZV926 at FL 80. MAX 220 KT IAS at ZV924. Cross OTBIG at or above 3000 FT.	As cleared by ATC.	OTBIG
KUNEM 2Q  (KUNEM TWO QUEBEC ARRIVAL)	From KUNEM to ZV935, to IPMAR, to ZV932, to ZV931, to ZV930, turn right to NEXUT.	Cross KUNEM at or above FL 100. Cross ZV935 between 3000 FT and FL 80. MAX 220 KT IAS at IPMAR. Cross NEXUT at or above 3000 FT.	As cleared by ATC.	NEXUT
RIVEX 2Q  (RIVEX TWO QUEBEC ARRIVAL)	From RIVEX to ZV936, to ZV934, to ZV933, to IPMAR, to ZV932, to ZV931, to ZV930, turn right to NEXUT.	Cross RIVEX at or above FL 100. Cross ZV936 between FL 80 and FL 120. MAX 220 KT IAS at ZV934. Cross NEXUT at or above 3000 FT.	As cleared by ATC.	NEXUT
ROPNO 2Q  (ROPNO TWO QUEBEC ARRIVAL)	From ROPNO to ZV927, to ZV924, to BEVGU, to ZV923, to ZV922, to ZV921, to ZV920, turn left to OTBIG.	Cross ROPNO at or above FL 100. Cross ZV927 between FL 80 and FL 90. MAX 220 KT IAS at ZV924. Cross OTBIG at or above 3000 FT.	As cleared by ATC.	OTBIG
UNBUD 2Q  (UNBUD TWO QUEBEC ARRIVAL)	From UNBUD to ZV934, to ZV933, to IPMAR, to ZV932, to ZV931, to ZV930, turn right to NEXUT.	Cross UNBUD at or above FL 100. Cross ZV934 between 4000 FT and FL 80. MAX 220 KT IAS at ZV934. Cross NEXUT at or above 3000 FT.	As cleared by ATC.	NEXUT
UPDER 3Q  (UPDER THREE QUEBEC ARRIVAL)	From UPDER to SOGTI, to BEGOD, to ZV500, to ZV925, to BEVGU, to ZV923, to ZV922, to ZV921, to ZV920, turn left to OTBIG.	Cross SOGTI at or above 7000 FT. Cross ZV500 at or above 4000 FT. Cross ZV925 between 4000 FT and FL 80. MAX 220 KT IAS at BEVGU. Cross OTBIG at or above 3000 FT.	As cleared by ATC.	OTBIG