

ENZV STAR RWY 28 (RNAV) – ROUTES

GENERAL:Surveillance service shall be available.

LOSS OF RNAV CAPABILITY:Request vectoring.

VECTORIZING:Vectoring may be used for sequencing.

DESIGNATOR	ROUTE	RESTRICTIONS	DESCEND	CLEARANCE LIMIT
BEGOD 2R  (BEGOD TWO ROMEO ARRIVAL)	From BEGOD, to ZV967, to ZV964, to ZV963, to TUSRU, to ZV962, to ZV961, to ZV960, turn right to EMPIS.	Cross BEGOD at or above 7000 FT. Cross ZV964 between 4500 FT and FL 80. MAX 220 KT IAS at ZV961. MAX 210 KT IAS at ZV960. Cross EMPIS at or above 4500 FT.	As cleared by ATC.	EMPIS
IDIPI 2R  (IDIPI TWO ROMEO ARRIVAL)	From IDIPI, to ZV972, to ZV966, to TUSRU, to ZV962, to ZV961, to ZV960, turn right to EMPIS.	Cross IDIPI at or above FL 100. Cross ZV972 at or above 8000 FT. Cross ZV966 between 6000 FT and FL 80. MAX 230 KT IAS at TUSRU. MAX 220 KT IAS at ZV961. MAX 210 KT IAS at ZV960. Cross EMPIS at or above 4500 FT.	As cleared by ATC.	EMPIS
KUNEM 3R  (KUNEM THREE ROMEO ARRIVAL)	From KUNEM, to ZV973, to ZV954, to ZV953, to ETPAN, to ZV952, to ZV951, to ZV950, turn left to OKOBO.	Cross KUNEM at or above FL 100. Cross ZV973 at or above FL 90. Cross ZV954 between 4100 FT and FL 80. MAX 220 KT IAS at ZV951. MAX 210 KT IAS at ZV950. Cross OKOBO at or above 4100 FT.	As cleared by ATC.	OKOBO
RIVEX 3R  (RIVEX THREE ROMEO ARRIVAL)	From RIVEX, to ZV974, to ZV956, to ETPAN, to ZV952, to ZV951, to ZV950, turn left to OKOBO.	Cross RIVEX at or above FL 100. Cross ZV974 at or above 8000 FT. Cross ZV956 between 4100 FT and FL 80. MAX 240 KT IAS at ETPAN. MAX 220 KT IAS at ZV951. MAX 210 KT IAS at ZV950. Cross OKOBO at or above 4100 FT.	As cleared by ATC.	OKOBO
ROPNO 2R  (ROPNO TWO ROMEO ARRIVAL)	From ROPNO, to ZV970, to ZV971, to ZV965, to ZV963, to TUSRU, to ZV962, to ZV961, to ZV960, turn right to EMPIS.	Cross ZV970 at or above FL 100. Cross ZV971 at or above 8000 FT. Cross ZV965 between 5000 FT and FL 80. MAX 230 KT IAS at ZV963. MAX 220 KT IAS at ZV961. MAX 210 KT IAS at ZV960. Cross EMPIS at or above 4500 FT.	As cleared by ATC.	EMPIS
UNBUD 3R  (UNBUD THREE ROMEO ARRIVAL)	From UNBUD, to ZV968, to ZV969, to ZV957, to ZV954, to ZV953, to ETPAN, to ZV952, to ZV951, to ZV950, turn left to OKOBO.	Cross ZV968 at or above FL 100. Cross ZV969 at or above 8000 FT. Cross ZV957 between 4100 FT and FL 80. MAX 220 KT IAS at ZV951. MAX 210 KT IAS at ZV950. Cross OKOBO at or above 4100 FT.	As cleared by ATC.	OKOBO
UPDER 3R  (UPDER THREE ROMEO ARRIVAL)	From UPDER, to SOGTI, to BEGOD, to ZV967, to ZV964, to ZV963, to TUSRU, to ZV962, to ZV961, to ZV960, turn right to EMPIS.	Cross BEGOD at or above 7000 FT. Cross ZV964 between 4500 FT and FL 80. MAX 220 KT IAS at ZV961. MAX 210 KT IAS at ZV960. Cross EMPIS at or above 4500 FT.	As cleared by ATC.	EMPIS