

AIRCRAFT PARKING/DOCKING CHART	APRON ELEV 83 FT	ATIS GND TWR TWR TWR TWR TWR	126.030 MHZ 121.855 MHZ 257.800 MHZ 369.325 MHZ 308.775 MHZ 120.105 MHZ 118.005 MHZ	HARSTAD/NARVIK, EVENES NORWAY
--------------------------------	---------------------	--	---	----------------------------------

GEO COORDINATES FOR AIRCRAFT STANDS

TERMINAL

AIRCRAFT STAND	CODE LETTER	GEO COORDINATES	ELEV
21		682933.53N 0164100.63E	82 FT
22		682931.75N 0164100.58E	82 FT
23		682929.34N 0164100.47E	82 FT
24		682927.03N 0164100.73E	82 FT
25		682925.75N 0164102.55E	83 FT
26		682924.32N 0164102.79E	83 FT
26B		682923.32N 0164103.61E	83 FT
26C		682923.43N 0164101.42E	82 FT
27		682923.65N 0164106.39E	84 FT
28		682923.70N 0164109.94E	84 FT
29		682923.75N 0164113.49E	84 FT
30		682923.80N 0164117.06E	83 FT

MIL APRON WEST

AIRCRAFT STAND	GEO COORDINATES	ELEV
P1	682831.20N 0164005.65E	68 FT
P2	682832.16N 0164009.77E	68 FT
P3	682833.12N 0164013.88E	68 FT
P4	682834.09N 0164017.99E	68 FT
P5	682835.05N 0164022.11E	68 FT

P10

AIRCRAFT STAND	CODE LETTER	GEO COORDINATES	ELEV
P10		682849.33N 0164024.02E	77 FT

CHANGES: P10, MIL APRON WEST, FREQUENCIES.