

## ENFL RNP X RWY 07 - RECOMMENDED CODING

SN	PD	WI	Fly-over	°M(°T)	MAG VAR	DIST (NM)	REC NAVAID	TD	ALT (FT)	Speed (KT)	VPA(°)/ TCH(FT)	ARC CENTRE RADIUS (NM)	RNP (NM)
010	IF	TOTVU	-	-	-1.0	-	-	-	A2000+	-	-	-	1.0
020	TF	XERGU	-	-	-1.0	10.1	-	-	A2000+	-	-	-	1.0
030	TF	FL605	-	-	-1.0	7.3	-	-	A1500+	-	-	-	1.0
040	TF	FL604	Y	-	-1.0	2.8	-	-	-	-	-3.7/50	-	1.0
050	DF	FL601	-	-	-1.0	-	-	R	-	-	-	-	1.0
060	TF	FL602	-	-	-1.0	7.4	-	-	-	-	-	-	1.0
070	TF	EV BON	-	-	-1.0	9.1	-	-	A2000	-	-	-	0.3
080	HM	EV BON	-	267 (268.3)	-1.0	3.5*	-	L	A2000	K100-	-	-	1.0
090	HM	XERGU	-	053 (053.8)	-1.0	1 MIN	-	R	A2000	-	-	-	1.0

\* 3.5 NM FM EVBON

Note: Recommended coding is based on ARINC 424 and is provided solely to indicate which procedure design protection areas were used in the Instrument Flight Procedure Design process.

Note: XERGU holding not included in standard APCH transitions.