



CHANGES: R123 ADDED.



NOTE:
ENGM, ENNO, ENRY, ENTO SID ENDPOINTS/STAR STARTPOINTS ARE SHOWN.
SIGNIFICANT POINTS ON FIR-BOUNDARY ARE SHOWN.

ATS AIRSPACE CLASSIFICATION: REF ENR 1.4 AND ENR 2.1.
SIGNIFICANT POINT: REF ENR 4.4.
RADIO NAVIGATION AID: REF ENR 4.1.
LEGEND: REF GEN 2.3.

SCALE 1: 1 200 000



D Area	Upper Limit	Lower Limit
D 104	4000 FT	GND
D 105	FL 130	GND
D 106	7000 FT	GND
D 107	6000 FT	4500 FT
D 108	6000 FT	3500 FT
D 109	6000 FT	3500 FT
D 110	FL 210	GND
D 111	4500 FT	GND
D 112	6000 FT	3500 FT
D 113	6000 FT	2500 FT
D 114	6000 FT	3500 FT
D 115	6000 FT	3000 FT
D 116	6000 FT	4500 FT
D 117	7000 FT	5500 FT
D 118	6000 FT	4500 FT
D 119	4000 FT	3500 FT
D 120	7000 FT	4500 FT
D 121	4000 FT	3500 FT
D 122	7000 FT	4500 FT
D 123	6000 FT	4500 FT
D 124	FL 90	5500 FT
D 125	7000 FT	5500 FT
D 126	7000 FT	5500 FT
D 127	7000 FT	4500 FT
D 128	6000 FT	4500 FT
D 129	6000 FT	3500 FT
D 130	6000 FT	4500 FT
D 131	7000 FT	4500 FT
D 132	6000 FT	4500 FT
D 133	7000 FT	4500 FT
D 134	7000 FT	5500 FT
D 135	7000 FT	5500 FT
D 136	7000 FT	4500 FT
D 137	6000 FT	4500 FT
D 138	6000 FT	4500 FT
D 139	7000 FT	4500 FT
D 140	7000 FT	3500 FT
D 141	7000 FT	3500 FT
D 142	6000 FT	3500 FT
D 143	6000 FT	3000 FT
D 153	FL 460	MSL
D 156	FL 160	GND
D 157	FL 290	GND
D 158	FL 360	GND
D 161	FL 185	AIP ENR 5.1
D 162	FL 225	AIP ENR 5.1
D 163	FL 225	AIP ENR 5.1
D 166	FL 225	AIP ENR 5.1
D 167	FL 660	GND
D 168	FL 95	GND

R Area	Upper Limit	Lower Limit
R 102	3000 FT	GND
R 103	2000 FT	GND
R 104	1000 FT	GND
R 105	1500 FT	GND
R 106	1500 FT	GND
R 107	1500 FT	GND
R 108	1500 FT	GND
R 109	AIP ENR 5.1	GND
R 110	AIP ENR 5.1	GND
R 111	AIP ENR 5.1	GND
R 112	AIP ENR 5.1	GND
R 113	AIP ENR 5.1	GND
R 114	AIP ENR 5.1	GND
R 115	AIP ENR 5.1	GND
R 116	AIP ENR 5.1	GND
R 117	2500 FT	GND
R 119	3000 FT	GND
R 120	3000 FT	GND
R 121	400 FT	GND
R 122	2500 FT	GND
R 123	1500 FT	GND